


USE AND CARE GUIDE

VERTICAL WALL GARDEN 24 in X 24 in



Questions, problems, missing parts? Before returning to the store, call Customer Service
8 a.m. - 6 p.m., EST, Monday - Friday

01 800 004 66 33

HOMEDEPOT.COM

THANK YOU

Table of Contents

Table of Contents	
•	• • • • • • • • • • • • • • • • • • • •
•	Care and Cleaning5
Planning Assembly2	
Tools Required	
Hardware Included2	
Package Contents3	

Warranty

This product carries no warranty. No replacement parts are available.

If there are any questions, contact the Customer Service Team at 01 800 004 66 33 or visit www.HomeDepot.com.

Pre-Assembly

PLANNING ASSEMBLY

Read all safety warnings and instructions carefully and thoroughly before assembling and using. Familiarize yourself with the inventory of parts and accompanying illustrations to ensure safe and proper assembly. The manufacturer is not responsible for any injury that may occur during the assembly of this product.

Place the parts on a soft surface to assemble and to prevent scratching the finish.

TOOLS REQUIRED (Not Included)




HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.








Part	Description	Quantity
AA	M6 Bolt: Metric - M6 x 15 mm and Standard Equivalent - 015/64 in x 015/32 in	2
ВВ	Hex wrench Std. Equiv Metric Short Arm Hex Key Set (10-Piece)	1
CC	M6x27 mm Plastic plug Std. Equiv #10 x 12 tpi x 1 in.	4
DD	M6x50 mm Concrete nail Std. Equiv 2 in. 6D Steel Fluted Masonry Nails	4

Pre-Assembly (continued)

PACKAGE CONTENTS



Part	Description	Quantity
Α	Left Panel	1
В	Right Panel	1
С	Planter	4


3

HOMEDEPOT.COM

Assembly


1 Assembling the frame

- Attach the left panel (A) to the right panel (B) by inserting the hinge of the right panel (B) into the ledge of the left panel (A).
- Secure both panels together using bolts (AA). Tighten the bolts using the hex wrench (BB).




Attaching the planter


□ Attach the planters (C) to the assembled frame.



3 Preparing to mount on a wall


- Locate and mark the desired mounting position according to the hanging holes on the garden.
- Drill holes into the wall at the marked locations and insert the plastic plugs (CC) into each hole.
- ☐ Hammer the concrete nails (DD) into the plastic plugs (CC).





4 Hanging the garden

□ Carefully hang the garden on the concrete nails (DD).




Adding Drain Holes (Optional)



CAUTION: Drilling too closely to the edge of the planters could compromise the structural integrity of the planters.

If you wish to add drain holes to the bottom of the planters (for exterior applications):

- □ Mark a spot on the bottom of each of the planters as shown.
- □ Use a 1/8 in. (3 mm) drill bit to drill a hole through each mark. Use a metal paint to cover the exposed metal (not included).



5

Care and Cleaning

- Do not use a scrub brush.
- If the paint chips, use paints and a brush to fix.
- If rust is showing, sand lightly and repaint the area with paints.
- Clean with a soft cloth.
- Cover the unit when not in use to prolong the life.
- Keep your product out of rain.



Imported by: Servicios Home Depot, S. de R.L. de C.V. Ricardo Margain 605, Santa Engracia San Pedro Garza García, N.L. México C.P. 66267 Tel.: 01 800 004 6633

Questions, problems, missing parts? Before returning to the store, call Customer Service
8 a.m. - 6 p.m., EST, Monday - Friday

01 800 004 66 33

HOMEDEPOT.COM

Handcrafted by artisans in India.

Retain this manual for future use.